

Accessories Flange as a clamping point for installation in press dies see page 3

**Electrical accessories** see page 5

Hydraulic power units see product group 7

Hydraulic accessories see product group 11

Application

gle. Monitoring of the clamping and unclamping position by inductive proximity switches. The swing mechanism is protected by a spring-loaded overload protection and equipped with manual emergency operation. Tie rod, piston and swing mechanism are hardened. The hydraulic system is protected by a wiper ring.

Swing clamps are installed in press rams

or press beds, in machine tools and plants.

Thanks to the compact design, they are particularly suitable where space is limited. Use at ambient temperatures up to max. 70 °C

#### **Connecting possibilities**

Two alternatives are offered for connecting the swing clamps.

#### **Pipe connection**



Swing clamp, double acting, with 90° swing an-

upper position and the swing clamps are extended.

#### **Advantages**

with 90° swing angle, clamping force from 60 to 412 kN

double acting, max. operating pressure 400 bar

- Ideal force transmission
- Compact design
- Clamping force from 60 up to 412 kN
- High operating safety by position monitoring, manual emergency operation and overload protection
- Suitable for large clamping edge tolerances  $(\pm 1.5 \text{ mm})$
- No colliding edges when inserting the dies
- Optimum utilisation of the ram area
- Clamping at difficultly accessible points



WZ 4.2170

Issue 1-20 US

# ROEMHELD

Swing Clamps

HILMA = STARK

Ì

Pipes are recommended in applications where fittings are easily accessible and where pipes do not impede installation and dismantling of the swing clamps.

#### Manifold-mounting connection



Hydraulic oil is fed through the drilled holes in the bed and in the ram. There are no exposed pipes or fittings. The sealing is made by O-rings supplied with the clamp. Easy installation, ease of servicing.

### Application example



Use of swing clamps in the press ram. Shown is the die change position, i.e. the ram is in the



## **Technical data Dimensions**



 $\oplus$ 

2174 = 8x2 2175 = 11x2 2176 = 11x2

.

C

Øe

hilli de la constantia de Ø c e8

Overload protection

Manual emergency operation to swing SW

<b>Technical data</b> Max. operating pressure 400 bar						
Clamping force at 400 bar	[kN]	60	104	164	256	412
Clamping force at 100 bar	[kN]	15	26	41	64	103
Piston Ø e	[mm]	54	70	88	110	140
Rod Ø d	[mm]	32	40	50	63	80
Swing stroke i	[mm]	13	18	24	28	35
Clamping and sink stroke h	[mm]	5	6	6	6	6
Oil volume clamping	[cm <sup>3</sup> ]	22	52	107	192	381
Oil volume unclamping	[cm <sup>3</sup> ]	34	77	158	286	570
Max. flow rate	[cm <sup>3</sup> /s]	10	16	25	75	150
а	[mm]	128	160	192	238	292
b	[mm]	84	104	122	165	182
С	[mm]	82	104	126	160	200
f	[mm]	M24x1.5	M30x1.5	M36x1.5	M45x1.5	M58x1.5
g		G 1/4	G 3/8	G 3/8	G 1/2	G 1/2
k	[mm]	13	17	21	25	31
1	[mm]	55	70	87	101	122
m	[mm]	18	23	28	33	40
n	[mm]	51	68	85	99	120
0	[mm]	20	26	33	40	48
р	[mm]	13	18	22	26	33
q	[mm]	34	42	52	63	80
r	[mm]	65	80	95	110	135
S	[mm]	70	86	103	120	147
t	[mm]	104	130	156	194	240
u	[mm]	30	38	45	60	75
V	[mm]	20	28	35	42	52
W	[mm]	38	47	59	71	88
х	[mm]	5.5	8	8	10	10
У	[mm]	70	86	103	120	147
Z	[mm]	4	5	6	14	14
(Manual emergency operation) SW2	[mm]	6	8	10	24	32
Draw-off thread AG1		M8	M10	M12	M 12	M16
Weight	[kg]	4.2	8.6	15	34	60
with pipe connection						
Part no.		2174 160	2175160	2176 160	2177 160	2178160
with manifold-mounting conn Part no.	ection	2174200	2175200	2176200	2177200	2178200

Further sizes and special versions are available on request



#### Important note!

Access to one of the two manual emergency operations is essential.

•

#### Mounting hole

#### for manifold-mounting or pipe connection





Manifold-mounting connection requires a plain and neat surface.

#### Accessory

Flange as a clamping point for installation in press dies



#### Flange - low



Flange - high



#### Mounting hole







Clamp	type	2174160 2174200	2175160 2175200	2176160 2176200
а	[mm]	128	160	192
k	[mm]	13	17	21
	[mm]	55	70	87
m	[mm]	18	23	28
0	[mm]	20	26	33
р	[mm]	13	18	22
S	[mm]	70+3	86+4	103+5
t	[mm]	104	130	156
W	[mm]	38	47	59
у	[mm]	70	86	103
Flange - low				
Part no	<b>).</b>	5700016	5700017	5700018
Flange	- high			
Part no	<b>)</b> .	5700019	5700020	5700021

Clamp type		2177160 2177200	2178160 2178200	
а	[mm]	238	292	
k	[mm]	24,5	31	
	[mm]	101	122	
m	[mm]	33	40	
0	[mm]	40	48	
р	[mm]	26	33	
S	[mm]	130	160	
t	[mm]	194	240	
W	[mm]	71	88	
у	[mm]	120	147	
Flange -	low			
Part no.		5700039	5700041	
Flange - high Part no.		5700040	5700042	

•

•

### Functional description Functional diagram

#### **Functional description**

Double acting swing clamp, with 90° swing angle. Monitoring of the clamping and unclamping position by inductive proximity switches. The swing mechanism is protected by a spring-loaded overload protection and equipped with manual emergency operation. Tie rod, piston and swing mechanism are hardened. The hydraulic system is protected by a wiper ring.

#### Hydraulic circuit diagram



## Clamping

- 1. Push and position the die into the press with the swing clamps in the off-position.
- 2. Lower the press ram onto the upper part of the die.
   The tie rods of the swing clamps will pass through the clamping slots of the upper die.

3. The swing clamps are operated by means of a power unit.
The tie rod rotates by 90° and is then in a transverse position to the clamping point.

The upper die is hydraulically clamped. Once the clamping pressure has been reached the power unit will be switched off by the pressure switch 1S2.

In the case of a pressure drop, the power unit is switched on by the pressure switch and builds up to the required clamping pressure.

#### Unclamping



1. Move the dies together and return the swing clamps into the unclamping position by means of energising valves Y1 and Y2.

The tie rod rotates by 90° and can then pass through the clamping slot of the upper die.

2. Move the press ram upwards and take the die out.

The clamping and unclamping positions are monitored by inductive proximity switches.



#### Hydraulic installation

Read the operating manual before starting up. Adjust the flow rate of the power unit so that clamping and unclamping cycles between 10 and 30 seconds are obtained. In order to prevent the swing mechanism from premature wear, the dynamic pressure at port B should not exceed 50 bar while the tie rods retract through the slot.

Swing clamps which are grouped together

#### **Electrical installation**

Connection of the monitoring system for clamping and unclamping position



Both proximity switches are connected to the base of the swing clamp through a connecting cable with screw coupling [IP 67]. Please order the connecting cable separately. Further installation may be carried out using a distribution board with an LED display.

## Pin assignment for three-wire proximity switches



should be connected to distribution boards, in order to avoid series connection. Use pipes with larger diameter for connection to the power unit.

If in doubt, please send the installation plan to be reviewed.

Provide a pressure gauge connection in every hydraulic circuit for adjustment and to check operating data.

#### Accessories

# 5-pole connecting cable with screw coupling





Cable length 5 m Cable length 10 m = black Ø

Part no. 5700013 Part no. 5700014 Accessories

#### Distribution board with LED display for the connection of 4 clamps

Display of the unclamping, change-over and clamping position of each clamping element via LED display.

Other parameters and recommendations for

hydraulic installation of die clamping systems

are given in chapter no. 1 "General information".

#### Delivery

- 1 distribution board
- 4 5-pole coupling plug
- 1 16-pole coupling plug

#### Part no. 5700015



Pin assignment of output plug:				
$\begin{array}{llllllllllllllllllllllllllllllllllll$	L = unclamping position U = not assigned S = clamping position			